

CEILING HOIST OPERATING INSTRUCTIONS

The maximum Safe working load for this hoist is 200kg, this hoist is not to be used by persons above this weight.

If the red light is on, do not use this hoist. If there is any doubt about the safety of using this hoist, it MUST NOT be used.



1. Use the control to raise or lower the carry bar to the required height.



2. Attach the hooks of the sling in the carry bar hooks. Check the sling is securely attached before lifting the person



3. Check nothing will stop the hoist from lifting the person.
4. Use the control buttons to raise the person, press the ↑ button to raise and the ↓ button to lower.
5. After use, return hoist next to change table
6. Emergency lowering strap can be used to lower a person in an emergency. Pull the red strap (once/continuously). Once activated the hoist will not operate until the cord & button is manually pressed in.



Please report maintenance issues to the Shire of Narrogin Administration Building at 89 Earl Street, Narrogin WA 6312
Phone: (08) 9890 0900